

Fixed Wing Aircraft

Fixed Wing Aircraft Assembly Instructions

1. Remove all aircraft parts from case and lay them out. Each case will be packed with 2 aircraft. Separate parts for each aircraft.



2. Insert the stabilizer rod into the hole in the center end of each wing and slide wings together. The wing spar can be verified on an assembled aircraft by observing the green color when looking through the cutout in the top of the wing assembly. If the wing spar is not present, you will observe a red color in the wing cutout.



Fixed Wing Aircraft – Assembly Instructions



3. Install the tail section by inserting the tail booms into the holes on the back side of the wings. Verify that the tail section is seated correctly by inserting the tail booms until the green band is touching the connector on the right wing. Secure the tail section by tightening the thumb screws on the wing connection points.



4. Set the wing and tail section on the top of the aircraft and press in. Secure the assembly to the fuselage using the 4 thumb screws located on the top of the wing assembly.



Fixed Wing Aircraft – Assembly Instructions



Kairos Autonomi
6700 S. Sandy Pkwy.
Sandy, Utah 84070
801-255-2950 (office)
801-907-7870 (fax)
www.kairosautonomi.com

PRODUCT BRIEF
Fixed Wing Assembly Instructions

Version History

Name	Date/Version	Description	Reason
Nicholas Ronnie	7/30/2024	Re-Formatting	

Fixed Wing Aircraft – Assembly Instructions